



FX4000RA 01

RD No.	PARTS NAMES	RD No.	PARTS NAMES	RD No.	PARTS NAMES
0041	Drive Gear Washer	1958	Bushing	4267	Bail Trip Lever Washer
0050	Anti-Reverse Lever Screw	2016	Drag Washer "H" (cloth)	4269	Anti-Reverse Lock Out
0080	Line Roller	2257	Drag Washer "H" (blue)	4270	Anti-Reverse Pawl
0111	Drag Coil Spring	2293	Drive Gear Bushing	4271	Anti-Reverse Cam
0452	Drag Spring Washer	2346	Drag Washer "C" (cloth)	4272	Drive Gear
0540	Multi-Purpose Screw	2433	Pressure Screw	4274	Drag Shaft
0579	Eared Washer "B"	2541	Anti-Reverse Pawl Screw	4275	Drag Knob
0584	Hold Click Spring	2852	Handle Screw Lock	4290	Main Shaft Assembly
0779	Multi-Purpose Screw	3681	Bail Spring Guide (A)	4310	Drag Click
0786	Trigger Screw	3682	Bail Spring	4362	Side Cover Screw
0815	Line Roller Washer	3692	Anti-Reverse Pawl Spring	4367	Line Roller Screw
0826	Key Washer "A"	3695	Oscillating Gear	4379	Anti-Reverse Lever
1008	Handle Lock Washer	3747	Slider Retainer Screw	6863	Spool Assembly
1030	Handle Assembly	3766	Oscillating Slider	6864	Bail Arm
1442	Handle Screw Cap	3767	Oscillating Slider Retainer	6865	Bail Assembly
1511	Lever Spring	3794	Drag Knob Screw	6866	Quick-Fire II Trigger
1520	Anti-Reverse Cam Spring	4262	Rotor Assembly	6867	Side Cover
1951	Rotor Lock	4264	Bail Spring Guide (B)	6868	Body
1955	Anti-Reverse Lock Out Spring	4265	Bail Spring Cover		
1957	Bushing Washer	4266	Bail Trip Lever		